


If you're unsure which size to buy, try measuring a Tri suit that you already own that fits you well, and compare those measurements to the size chart. Lay the Tri suit on a flat surface and use the above guide to measure the Tri suit.

Note: All measurements are approximate.


Size	A (Chest)	B (HIP)	C (F.CROTCH)	D (B.CROTCH)	E (INSEAM)
XS	14 1/4"	15 1/2"	22 1/4"	28 1/2"	7 1/2"
S	14 3/4"	16"	23 1/2"	29 3/4"	7 3/4"
M	15 1/4"	16 1/2"	24 3/4"	31"	8"
L	15 3/4"	17"	26"	32 1/4"	8 1/4"
XL	16 1/4"	17 1/2"	27 1/4"	33 1/2"	8 1/2"
2XL	16 3/4"	18"	28 1/2"	34 3/4"	8 3/4"
3XL	17 1/4"	18 1/2"	29 3/4"	36"	9"
4XL	17 3/4"	19 "	31"	37 1/4"	9 1/4"



If you're unsure which size to buy, try measuring a ITU Tri suit that you already own that fits you well, and compare those measurements to the size chart. Lay the ITU Tri suit on a flat surface and use the above guide to measure the ITU Tri suit.

Note: All measurements are approximate.

Size	A (Chest)	B (HIP)	C (F.CROTCH)	D (B.CROTCH)	E (INSEAM)
XS	13 3/4"	15"	21"	27 1/4"	7 1/4"
S	14 1/4"	15 1/2"	22 1/4"	28 1/2"	7 1/2"
M	14 3/4"	16"	23 1/2"	29 3/4"	7 3/4"
L	15 1/4"	16 1/2"	24 3/4"	31"	8"
XL	15 3/4"	17"	26"	32 1/4"	8 1/4"
2XL	16 1/4"	17 1/2"	27 1/4"	33 1/2"	8 1/2"
3XL	16 3/4"	18"	28 1/2"	34 3/4"	8 3/4"
4XL	17 1/4"	18 1/2"	29 3/4"	36"	9"



If you're unsure which size to buy, try measuring a ITU Tri suit that you already own that fits you well, and compare those measurements to the size chart. Lay the ITU Tri suit on a flat surface and use the above guide to measure the ITU Tri suit.

Note: All measurements are approximate.

Size	A (Chest)	B (HIP)	C (F.CROTCH)	D (B.CROTCH)	E (INSEAM)
JR-XS/TP 7-8	11"	12 1/2"	14"	22"	6"
JR-S/P 9-10	11 1/2"	13"	15 1/4"	23 1/4"	6 1/4"
JR-M 11-12	12"	13 1/2"	16 1/2"	24 1/2"	6 1/2"
JR-L/G 13-14	12 1/2"	14"	17 3/4"	25 3/4"	6 3/4"
JR-XL/TG 15-16	13 "	14 1/2"	19"	27"	7"